Menubar

The Menubar provides quick access to the Guide, CatchUp TV, Rentals, DVR, My Library, Cloud TV, Settings, Favorites, Search, Widgets, Web, Email and Parental Control features.



- Guide Launch the interactive program Guide
- CatchUp TV Watch recordings of programs
- Rentals Rent a movie to watch instantly on your TV
- DVR Watch, edit, and create DVR recordings
- Cloud TV Watch web-based videos or view photos on the TV
- My Library Review Upcoming Pay-Per-View events, scheduled Reminders, system messages, and TV Caller ID history
- Favorites Create or edit a favorite channels list
- Settings Access Settings for TV Caller ID, Channel Blocking, Parental Controls, and Hardware
- Web Browse the web on the TV
- Email Check your email on the TV
- Search Find your favorite programs by title or key word
- Widgets Access Widgets for Sports, Stocks, Twitter, Weather, Finance, and News
- Parental Controls On/Off Turn On or OFF Parental Controls to block programs by program rating. The Parental Controls option will only appear if the Parental Controls box is checked in Settings.

To access the Menubar:

- a) Press **Menu** on your remote control. Press **Menu** again to edit or press **Edit** on your remote control.
- b) Press the **Left/Right** buttons on your remote control to navigate the highlight through the **Menu**.