

Infobar

The InfoBar provides quick access to information about the programs that are on now or will be on in the future.



You can access the Infobar three ways:

1. Press **Info** on your remote control. Press **Info** again to display a more detailed program description.
2. Press the **Up/Down** buttons on your remote control.
3. When changing channels, the **Infobar** will appear automatically.

Navigate Using the Infobar

When the Infobar is present on the screen, you can perform the following actions without leaving the channel you are on.

- a) Press **OK** on the remote to **Record Program, Record Series, or Expand Info** for the current program you are viewing.
- b) Navigate to other channels by pressing the **Up/Down** arrows and press **OK** to tune to that channel.
- c) Navigate to future programs by pressing the **Left/Right** arrows. Press **OK** while viewing the **Infobar** for a future program to: **Schedule Event, Record Program, Record Series, Set Reminder, Set Autotune, Expand Info**. Use the arrow buttons on the remote to move the highlight through the actions and press **OK** to select.

Note: Recording options will be available to DVR subscribers only.